



Assembly and Installation Instructions

1. Release the strings



Your RBS will arrive with the strings tied up in a bow.

Untie the bows and let the strings fall to the ground.

You must check to be sure the strings are completely unrolled from the roller cassette before you begin to string your shade. Each string is 144" long. The string will be straight across the cassette when it is completely unrolled. (See the picture on the right.) The string closest to the clutch goes across to the eye and then down through the rings.



Look inside the RBS string roller cassette to be sure the string is straight across left to right. This indicates the string is fully unrolled.

2. Attach your shade to board

Attach your shade to the board. Take off the levelers. Align the cassettes with your rings and then tighten the white screws to lock-in their position. String the shade through the rings. Cut the strings 4" longer than the shade to allow final leveling on site.

3. For Outside Mount

Remove the RBS from its brackets on the board. Mount the brackets on the wall. Put the RBS system back into the brackets



3. For Inside Mount

Remove the RBS from the bracket on the board. Screw up through the board to secure in place. Put the RBS system back into the brackets.



4. Reattach to the board & level the shade.



Reattach the RBS with shade to the brackets by hooking on to the front edge of the slot and pressing forward to compress and then release the spring loaded bracket once it is in place